



“Your Direct Source for Condition Monitoring, Test & Measurement”

www.ReliabilityDirectStore.com

2911 South Shore Blvd. Suite 170, League City, TX USA 77573 Phone: 281-957-5283 Fax: 281-334-4255

Phase Sequence Tester




Checks phase sequence and phase status

Tests up to 690VAC and displays graphical phase orientation on the large LCD

Features:

- 40 to 690VAC rated test range for testing phase orientation of three phase power sources over 15 to 400Hz frequency range
- Graphical multiline LCD indicates phase orientation (clockwise or counter-clockwise) and whether each of the three phases is live
- Durable housing is double molded
- Easy to open alligator clips with wide jaws
- Tests phase orientation of three phase power sources
- No battery required
- Dimensions: 5.1 x 2.7 x 1.25" (130 x 69 x 32mm); Weight: 4.5oz (130g)
- Complete with cable, three large color coded alligator clips, and pouch case



Easy to read graphical multilined LCD displaying phase orientation and showing which three phases is live



Ordering Information:

480400Phase Sequence Tester



RELIABILITY DIRECT, INC.

2911 S. Shore Blvd., Suite 170 League City, TX USA 77573 Tel: 281.957.5283 Fax: 281.334.4255

