

"Your Direct source for Plant reliability, Maintenance, Test & Measurement"
www.reliabilitydirectstore.com

2911 South Shore Blvd. Suite 170, League City, TX USA 77573 Phone: 281-291-957-5283 Fax: 281-334-4255





## **Wood Moisture Meter**

Integral pins and Remote hand-press probe

Monitor moisture in wood either directly with the built-in moisture pins or use remote hand-press
probe on hard surfaces. Designed in a rugged double molded housing construction and is
pocket sized for one-handed operation

## Features:

- Memory contains 8 wood groups with calibrations for approximately 170 species of wood
- Measurements can be taken using the integral pin electrodes (replaceable pins) or a heavy duty remote probe (included)
- Automatically temperature compensated (ATC) readings when used with the temperature probe (included)
- · Built-in calibration check
- · User settable Auto power off (1 to 9 minutes) with disable
- · Low battery indication
- Complete with remote hand-press moisture probe, Temperature probe, protective cap, replacement pins, pouch case, and two AAA batteries





## **Ordering Information:**

MO220.......Wood Moisture Meter MO220-PINS ..Replacement Moisture pins for MO220 (50pins)

