

## ExStik® EC400

# **Conductivity / TDS / Salinity / Temperature Meter**



CE

#### Introduction

Congratulations on your purchase of the ExStik® EC400 Conductivity/Total Dissolved Solids (TDS) / Salinity / Temperature meter. With the EC400's dynamic cell-constant technology it is possible to measure a wide range of Conductivity, TDS, and Salinity with the same electrode. Careful use and maintenance will provide years of reliable service.

## Powering the ExStik™

The ExStik® uses four (4) CR2032 Lithium Ion Batteries (included). If the batteries are weak, the 'BAT' indicator appears on the LCD. Press the ON/OFF key to turn the ExStik® on or off. The auto power off feature shuts the ExStik® off automatically after 10 minutes of inactivity to preserve battery life.

## **Getting Started**

- Remove the cap from the bottom of the ExStik to expose the conductivity electrode.
- Before the first use or after storage, rinse the electrode in deionized water and dry.
- For best results, calibrate for conductivity with a standard in the expected range of the sample. For maximum accuracy calibrate from low conductivity value standards to high value standards.
- Store dry.

## Warranty

EXTECH INSTRUMENTS CORPORATION warrants this instrument to be free of defects in parts and workmanship for one year from date of shipment (a six month limited warranty applies to sensors and cables). If it should become necessary to return the instrument for service during or beyond the warranty period, contact the Customer Service Department at (781) 890-7440 ext. 210 for authorization or visit our website www.extech.com for contact information. A Return Authorization (RA) number must be issued before any product is returned to Extech. The sender is responsible for shipping charges, freight, insurance and proper packaging to prevent damage in transit. This warranty does not apply to defects resulting from action of the user such as misuse, improper wiring, operation outside of specification, improper maintenance or repair, or unauthorized modification. Extech specifically disclaims any implied warranties or merchantability or fitness for a specific purpose and will not be liable for any direct, indirect, incidental or consequential damages. Extech's total liability is limited to repair or replacement of the product. The warranty set forth above is inclusive and no other warranty, whether written or oral, is expressed or implied.



#### Support line (781) 890-7440

Technical support: Extension 200; E-mail: support@extech.com Repair & Returns: Extension 210; E-mail: repair@extech.com

#### Product specifications subject to change without notice

For the latest version of this User's Guide, Software updates, and other up-to-the-minute product information, visit our website: www.extech.com

## **Specifications**

Display 2000 count LCD with Bargraph

Conductivity ranges 0 to 199.9µS/cm

200 to 1999µS/cm 2.00 to 19.99mS/cm

TDS ranges 0 to 99.9ppm or mg/L (Variable ratio) 100 to 999ppm or mg/L

1.00 to 9.99ppt or g/L

Salinity range 0 to 99.9ppm (Fixed ratio of 0.5) 100 to 999ppm

1.00 to 9.99ppt

TDS Ratio 0.4 to 1.0 adjustable

Salinity Ratio 0.5 Fixed Conductivity ATC 2.0% per °C

Temperature Range 0.0°C to 90.0°C (32.0°F to 194°F)

Temperature Resolution 0.1 up to 99.9, 1 >100

Temperature Accuracy ±1°C; 1.8°F (from 0 to 50°C; 32 to 122°F)

±3°C; 5.4°F (from 50 to 90°C; 122 to 194°F)

Conductivity ATC Range 0.0°C to 60.0°C (32.0°F to 140°F)

Accuracy Conductivity: ±2% full scale

TDS: ±2% full scale Salinity: ±2% full scale

Measurement Storage 25 tagged (numbered) readings

Low battery indication 'BAT' appears on the LCD

Power Four (4) CR2032 Lithium Ion Batteries
Auto power off After 10 minutes (override available)

Operating conditions -5°C to 50°C (23°F to 122°F)


Dimensions 40 x 187 x 40 mm (1.6 x 7.4 x 1.6")

Weight 87 g (3.1 oz)

## **Front Panel Description**

- 1. Battery compartment
- 2. LCD Display
- 3. MODE/HOLD button (change mode, Hold and store data)
- 4. CAL/RECALL button (Calibration, change temperature units and recall data.
- 5. ON/OFF button
- 6. Electrode Collar
- 7. Electrode

(Note: The Electrode cap is not shown)



## **LCD Display**

- 1. Bargraph display
- 2. Measurement units
- 3. Main display
- 4. Range calibration and low battery indicators
- 5. Temperature display
- 6. Reading Hold Indicator



#### **Sample Preparation:**

 For Conductivity, TDS or Salinity place the test sample in a sample cup with enough depth (2.5cm minimum) to cover the electrode. Stir the solution to remove any air bubbles.



#### Measurement:

- Depress and hold the MODE/Hold key to scroll to the desired measurement mode.
- Insert the electrode into the sample making sure that the electrodes are completely submersed.
- 4. Slowly stir the solution with the electrode to remove air bubbles.
- The meter will auto-range to the proper range and then display the reading.



#### **Conductivity**





<u>.. 52.0</u> הכי

TDS(mg/L)



Salinity



#### **Changing Measurement Function**

The meter can be set to measure Conductivity, TDS or Salinity. To change the mode:

 Press and Hold the MODE/HOLD button for 3 seconds and the display will begin to scroll through the units.

μS (Conductivity); ppm S (Salinity); ppm (TDS); mg/l (TDS);

**Note:** The "HOLD" function cannot be on when changing the measurement function. If "HOLD" is displayed in the lower left corner of the display, briefly press the MODE/HOLD button to turn it off.

2. When the desired units are displayed, release the MODE/HOLD button.

#### **TDS Compensation Ratio**

The TDS value is determined by multiplying a conductivity reading by a known ratio factor. The meter allows for selecting a conversion ratio in the range of 0.4 to 1.0. The ratio varies with the application, but is typically set between 0.5 and 0.7.

Note: The stored ratio will briefly appear in the lower temperature display when the meter is first turned on, or when changing measurement function to TDS.

#### Note: In the Salinity mode the ratio is fixed at 0.5.

To change the ratio, while in the TDS measurement mode (ppm or mg/l):

- Press and release the CAL/RECALL button twice in succession. The stored ratio will appear in the display.
- Press the MODE/HOLD button to increase the ratio value in steps of 0.1
- When the desired ratio is displayed, press and release the CAL/RECALL button to store the value and return to the normal mode.



4. If no buttons are pressed for 5 seconds, the meter returns to measure mode.


## **Storing Readings**

- Press the MODE/HOLD button to store a reading. The storage location number will be displayed on the lower display, while the main display shows the stored reading. The meter will enter the HOLD mode and the "HOLD" indicator will appear.
- Press the MODE/HOLD button again to exit the HOLD mode and return to normal operation.
- If more than 25 readings are stored, previously stored readings (starting with number 1) will be overwritten.



#### **Recalling Stored Readings**

 Press the CAL/RECALL button and then press the MODE/HOLD button. A location number (1 through 25) will briefly appear and then the value stored in that location will appear. The displayed units will flash, indicating that the storage recall mode is active.



- The last stored reading will be displayed first. Pressing and releasing the MODE/HOLD button will scroll through the stored readings one at a time. The location number is displayed first, followed by the reading stored in that location.
- To exit the storage mode, press the CAL/RECALL button and the meter will return to normal operation, after displaying "END".

#### **Clear Stored Memory**

With the unit on, press and hold ON/OFF for 4 seconds. "clr" will be briefly displayed when the memory is cleared.

#### **Changing Temperature Units**

To change the displayed temperature units (°C or °F):

- 1. With the unit OFF, press and hold down the CAL/RECALL button.
- With the CAL/RECALL button depressed momentarily press the ON/OFF button. When "SELF CAL" appears in the display release the CAL/RECALL button. The unit will power on with temperature displayed in the new units.

#### **Data Hold Mode**

Press the **MODE/HOLD** button to hold (freeze) a reading in the display. The meter will enter the HOLD mode and the "HOLD" indicator will appear.

Note: This also stores the reading.

Press the MODE/HOLD button again to return to normal operation.

#### **Auto Power OFF**

The auto power off feature automatically shuts the meter off 10 minutes after the most recent button press.

#### **Auto Power OFF Disengage Feature**

To disable the Auto Power Off feature:

- 1. Turn the unit on
- Press CAL/RECALL once (Quickly)
- Immediately and simultaneously press the MODE/HOLD and ON/OFF buttons for approximately 2 seconds, until "oFF" is briefly displayed

To disengage this feature, turn the unit off with the **ON/OFF** button. The next time the unit is powered up, Auto Power OFF mode will be engaged again.

7

#### Low Battery Indication

When the batteries become weak the "BAT" icon will appear in the display. Refer to the Maintenance section for battery replacement information.

#### **Measurement and Display Considerations**

- If the unit appears to be locked (display frozen). It is possible that the Data Hold mode
  has been inadvertently accessed by pressing the MODE button. ("HOLD" will be
  displayed in the bottom left of the LCD.) Simply press the MODE button again or turn
  the meter off and then on.
- If the meter does freeze, and no button presses revive it, perform a hard reboot as
  follows: Remove the batteries, hold the "ON" button down for 5 seconds, then replace
  the batteries. This resets the microprocessor, but does not clear stored readings or
  calibration data from memory.
- For maximum accuracy, allow sufficient time for the temperature of the probe to reach the temperature of the sample before calibrating. This will be indicated by a stable temperature reading on the display.

#### **Calibration - Conductivity**

Meter accuracy verification should be performed on a periodic basis. Once per month is the recommended cycle for normal use. If calibration is required, a conductivity standardizing solution must be obtained. The meter can be calibrated in any or all of the three ranges. Standardizing solutions of 84µS/cm, 1413µS/cm or 12.88mS/cm (12,880µS/cm) are used for the automatic calibration recognition procedure. No other calibration values are permitted.

Calibration is always done in conductivity mode. Since salinity and TDS values are calculated from conductivity values, this procedure also calibrates the salinity and TDS ranges.

- 1. Fill a sample cup with the standardizing solution.
- 2. Turn the meter ON and insert the electrode into the solution. Tap or move the electrode in the sample to dislodge any air bubbles.
- Press and hold the CAL/RECALL button (approximately 2 seconds) until "CAL" appears in the lower (temp) display. The main display will start flashing.
- The meter will automatically recognize and calibrate to the standardizing solution.
   The display will briefly indicate "SA", END and then return to the measurement mode after a calibration.
  - Note: The "SA" will not appear if the calibration fails.
- 5. The "range calibrated" symbol will appear in the display for each range that is calibrated during that power on cycle.
  - Low range, 84µS/cm
  - Medium range, 1413µS/cm
  - High range, 12.88mS/cm (12,880µS/cm)

Note: Each time the calibration mode is entered all calibration symbols on the display are cleared, but only the calibration data for the currently calibrated range is replaced. The other two ranges keep the existing calibration data, just the symbols are removed. Calibration of all three ranges must be performed during one power on period for all three range calibration symbols to appear.

Note: The meter allows for a 1, 2 or 3 point calibration. If calibration is done for more than one point the lowest value standard should be done first to obtain the best accuracy.

## Considerations and Techniques


- Do not touch the inner surfaces of the conductivity electrodes. Touching the surface of the platinized electodes may damage and reduce the life of the probe.
- Store the electrode dry, in the storage cap.
- Always rinse the electrode in de-ionized water between measurements to avoid cross contamination of the sample. Double rinsing is recommended when high accuracy is required.

## **Operational Matrix**

Function / Resulting Action	Power Status	Mode Setting	Required Key Press Sequence
On/Off	On or Off	Any	Momentary press of the On/Off key
Calibration	On	Conductivity	Press & hold CAL/RECALL key for 2 seconds, until it enters CAL function
Store Reading	On	Any measure mode	Momentary press of the MODE/HOLD key
Hold Release	On	While In Hold Mode	Momentary press of the MODE/HOLD key
Enter Memory Retrieval	On	Any measure mode	Momentary press of the CAL/RECALL key followed by a momentary press of the MODE/HOLD key (Within 4 seconds)
Scroll Stored	On	Memory Recall	Momentary press of the MODE/HOLD key
Readings			(Displays "last in first out")
Exit Memory Retrieval	On	Memory Recall	Momentary press of the CAL/RECALL key
Clear Stored Memory	On	Any Measure Mode	Press and hold the On/Off key for 4 seconds, until "Clr" is displayed.
Change Measureme nt Mode	On	Any	Press and hold the MODE/HOLD key for at least three seconds (the modes will scroll by until the key is released)
Enter Cond/TDS Ratio	On	TDS (ppm or mg/l)	Press and release the CAL/RECALL key twice in quick succession
Change Cond/TDS Ratio	On	TDS ratio	Momentary press of the MODE/HOLD key (each key press increases the ratio by 0.1, the value cycles from 0.4 - 1.0)
Exit Cond/TDS Ratio	On	TDS ratio	Momentary press of the CAL/RECALL key
Change Temperature Units	Off	n/a (off mode)	Press and hold the CAL/RECALL key then momentarily press the On/Off key. Release the CAL/RECALL key after the "Self Cal" lights
Override Auto Power Off	On	Any measure mode	Momentarily press the Cal Key then simultaneously press and hold the ON/OFF & MODE/HOLD key for approximately 2 seconds, until "oFF" is displayed
Default Reset	OFF	n/a	Simultaneously press ON/OFF, CAL/RECALL and MODE/HOLD momentarily. "dFLt" will be displayed.

#### **Battery Replacement**

- 1. Twist off the battery compartment cap.
- Holding the battery housing in place with a finger, pull out the battery carrier using the two small tabs.
- 3. Replace the four (4) CR2032 batteries observing polarity.
- 4. Replace the battery compartment cap



#### **Electrode Replacement**

- 1. To remove an electrode, unscrew and completely remove the electrode collar (turn the collar counter-clockwise to remove).
- Gently rock the electrode from side to side, pulling it downwards, until it disconnects from the meter.
- 3. To attach an electrode, carefully plug the electrode into the meter socket (note that the electrode connector is keyed, ensuring proper connection).
- 4. Tighten the electrode collar firmly enough to make a good seal (a rubber gasket seals the electrode with the meter).

## **Cleaning Recommendations**

When cleaning the probe, take care not to scratch or damage the platinized electrode surfaces.

Contaminant	Cleaning Solution	Instructions
Water soluble substances	Deionized water	Soak or scrub gently with a soft brush. Rinse thoroughly with DI water, and dry
Grease & Oil	Warm water and household detergent	Soak or scrub with a soft brush, maximum of 10 minutes. Rinse thoroughly with DI water, and dry
Heavy grease & Oil	Alcohol	Maximum of 5 minute soak, scrub with a soft brush. Rinse thoroughly with DI water, and dry
Lime and hydroxide coatings	10% acetic acid	Soak until coating dissolved, maximum of 5 minutes Rinse thoroughly with DI water, and dry.

## **Troubleshooting**

Problem	Possible Cause	Action
Reading is frozen	Unit is in "HOLD" mode	Press MODE/HOLD key to exit "HOLD" mode
"BAT" message	Batteries are low	Replace batteries
Unit will not calibrate in conductivity mode	Contaminated conductivity standards	Use fresh standards
Unit will not calibrate in conductivity mode	Dirty probe	Clean conductivity probe (See cleaning instructions)
Unit will not calibrate in conductivity mode	Damaged conductivity probe	Replace electrode
Unit will not calibrate in conductivity mode	Trapped air bubbles	Tap or stir to release air bubbles
Unit will not turn on	Batteries are low or dead	Replace batteries
Unit will not turn on	Batteries installed with incorrect polarity	Replace batteries, observe polarity
Unit will not respond to any key presses	Internal fault	Perform hard reboot: Remove batteries, hold ON/OFF switch down for 5 seconds, replace batteries

Copyright © 2005 Extech Instruments Corporation.

All rights reserved including the right of reproduction in whole or in part in any form.

www.extech.com